

# ZODIAC

## » INSTRUCTIONS OF USE



**X** Do not use as a step ladder

### INDOOR USE ONLY

To adjust back height —  
hold back with two hands  
while seated and raise to  
desired height

To lower the back height  
raise back all the way to  
the top and release slowly

**RIGHT LEVER**  
To adjust seat height



### 700MM ALUMINIUM 5 STAR BASE WITH CASTORS

Use soft tyred castors for tiles

Use hard tyred castors for carpet

- » Vacuum regular
- » Regularly adjust mechanism angle
- » Regularly adjust gas height
- » All warranty claims to be forwarded to place of purchase
- » Warranty covers components and workmanship only
- » Damage or wear and tear not covered by warranty
- » Misuse or abuse will not be covered under warranty